

SKREDDY PEDALS™
? Lady

Fat, Liquid, Sustaining, Vintage Fuzz with Extra Smoothness

Sustain: This controls the intensity of the fuzz and sustain. Different distortion character will come from different settings of this knob; darker and tamer to hotter and more aggressive.

Volume: This sets the output volume. Unity gain should be around noon.

Tone: This is a powerful tone-morphing control. At the center, you will have full, smooth tone. At left, you'll get a huge bassy sound, and at right, you'll get a brighter, more cutting sound.

Mids: The mini toggle at the top will render the tone stack with a classic slightly-scooped midrange when set to the left, and to the right, it will add juicy mids.

Power

9v battery is included. To prevent the battery from draining while the pedal is not in use, remember to un-plug the input cable from the pedal's input jack.

You may also supply external power through an AC adapter. All Skreddy Pedals accept the industry-standard 9v DC plug (5.5mm barrel x 2.1mm center coax), with the center being negative and the barrel being positive. Please use a quality, regulated, filtered power supply. The battery is disconnected from the circuit when an adapter is plugged into the DC jack.

Noise

Your ? Lady will not be silent when you are not playing. The transistors will have a bit of their own noise, but mainly being so high gain will amplify any ambient hum present in your signal.

Service

Email Skreddy Pedals at marc@skreddypedals.com if your ? Lady pedal needs repair.